CABINET PARTS

REFRIGERATOR

For Models: ET1FTTXKQ02, ET1FTTXKT02, ET1FTTXKB02
(White) (Biscuit) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Models: ET1FTTXKQ02, ET1FTTXKT02, ET1FTTXKB02
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	LIT2218878	Service & Wiring Sheet
	LIT2218838	Energy Label
	LIT2212841	Use & Care Guide
	LIT2218340	Customer Quick Tips
	LIT628370	Modular Icemaker Service Sheet
	LIT2210486	Instruction Sheet, Water Filter

Following May Be Purchased

DO−IT−YOURSELF REPAIR MANUALS

	LIT677969	Do−It−Yourself Manual Ref./Fzr.
2	2189410	Hinge (Top)
3	2166108	Roller, Front (2)
4		Cabinet (Not a Serviceable Part)
5	489385	Clamp, Tube (Water Supply Line)
6	8281265	Screw (7) 8−18 x 1/2
10	2179826	Rivet
11	3400504	Screw
12	549193	Clamp, Cord
15	489497	Screw
16	2183972	Hinge, Center
17	2183854	Shim, Hinge Center
18	489464	Screw
20	2189194	Hinge Butt
23	2172743	Shim, Bottom Hinge
24		Fitting, Water Tube (Not Serviced)
27		Hole Plug (6)
	2201012	White
	2200924	Biscuit
	2183998	Black
35		Corner Filler (2)
	2201014	White
	2200926	Biscuit
	2201017	Black
36		Grille
	2201006	White
	2201020	Biscuit
	2201008	Black
37	489341	Washer
38	487576	Washer
39	2189356	Clip−Grille
40		Cover−Hinge
	2213360	White
	2213364	Biscuit
	2213363	Black
41		Rail, Center (Not Serviced)
44	2202884	Cover, Unit

DOOR PARTS

For Models: ET1FTTXKQ02, ET1FTTXKT02, ET1FTTXKB02
(White) (Biscuit) (Black)



DOOR PARTS

For Models: ET1FTTXKQ02, ET1FTTXKT02, ET1FTTXKB02
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION
1		Refrigerator Door (Includes #9 & #22)
	2183920	White
	2205284	Biscuit
	2200714	Black
2		Handle, Trim
	2193353W	White
	2193353T	Biscuit
	2193353B	Black
3	8281206	Screw
5		Handle Center
	2213112W	White
	2213112T	Biscuit
	2213112B	Black
6	489357	Screw
8	8281146	Screw
9		Door Gasket, Magnetic
	2202875	Mist Beige
	2202882	Black
13		Nameplate
	2175383	White
	2205769	Biscuit
	2200944	Black
16	2195378	Trim, Door Shelf
17	489427	Screw
19		Freezer Door (Includes #22 & #23)
	2182489	White
	2204686	Biscuit
	2200711	Black
20		Hole Plug
	2189000	White
	2200936	Biscuit
	2189009	Black
21	2188236	Shelf, Flip−Up
22	2183003	Thimble
23		Door Gasket, Magnetic
	2214967	Mist Beige
	2214969	Black
25	2204812	Bin, Door Shelf
26	2189202	Bracket, Door Stop (2)
27	488921	Screw
28		Hole Plug
	2212648	White
	2212649	Biscuit
	2212651	Black
29	2156007	Plug, Trim
30	2156006	Plug, Trim
31	2218118	Compartment Door
33		Handle, F.C.
	2213111W	White
	2213111T	Biscuit
	2213111B	Black
37	2195947	Trim, Door (2)
41	2195916	Endcap (4)
42	2195948	Trim, Door

LINER PARTS

For Models: ET1FTTXKQ02, ET1FTTXKT02, ET1FTTXKB02
(White) (Biscuit) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

LINER PARTS

For Models: ET1FTTXKQ02, ET1FTTXKT02, ET1FTTXKB02
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Serviceable Part)
2	2197380	Grommet (2)
3	2221653	Gasket, Evaporator Cover (2)
4	2188376	Defrost Timer
5	2212485	Thermostat Tube Barrier
6	941839	Hole Plug
7	2187308	Wire Assembly, Control Box
8	2162085	Socket, Light (2)
9	2179858	Damper, Air
10	2214986	Fan Motor
11	2163777	Fan Blade
12	2210530	Control Box
13	2210491	Thermostat Assy. (Includes Items 5, 18 & 36)
14	489478	Screw
15	489464	Screw
16	2201175	Cover, Evaporator
17	527949	Light Bulb (2)
18	2200831	Weight, Thermal
19	1118894	Switch, Rocker Arm
20	2179859	Post, Damper
21	2176281	Cover, Air Diffuser
22	2200863	Knob, Thermostat
23	2182340	Air Tower
24	2189452	Air Diffuser, Bottom
25	2184617	Freezer Floor
26	2204690	Air Diffuser, Top
27	2176341	Clip, Retaining
28	2214981	Insulation, Water Tube
29	2218696	Bracket, Fan Motor
30	2214979	Bracket, Evap. Fan, Front
31	2204639	Shield, Heat
32	2214976	Bracket Evap. Fan, Rear
34	2176297	Knob, Damper
35	2163810	Bracket, Damper Knob
36	2205079	Seal, Rear Thermostat
38	2210509	Valve−Tube, Body
39	2219652	Wire Assembly, Freezer Compartment
44	2210510	Bracket Assembly, Water Filter
54	2210504	Cover, Filter
55	2210518	Tube, Filter Inlet
56	2210521	Cover, Tubing
57	2206039	Cartridge, Filter
58	2181943	Tube, Filter Outlet
59	2210563	Clip, Retainer

UNIT PARTS

For Models: ET1FTTXKQ02, ET1FTTXKT02, ET1FTTXKB02
(White) (Biscuit) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UNIT PARTS

For Models: ET1FTTXKQ02, ET1FTTXKT02, ET1FTTXKB02
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION
1	2205340	Plate, Unit Mounting
2	489478	Screw
3	2212599	Condenser
4	2166124	Heater, Defrost
5	2195390	Evaporator Assy.
6	3400518	Screw
7	2172620	Drain Pan
8	2221677	Defrost Bi−Metal
9	2176301	Bracket, Heater
10	2163780	Extension, Air Baffle
11	2212996	Strap
12	4387731	Cover (Service Only)
13	4387766	Overload (Service Only) (Includes Relay)
14		Grommet (4)
	1100826	Production
	4387558	Service
15	2218853	Start−Device Combination Start Relay and Overload for Production Compressor Only)
16	2201185	Support Block
17	2150304	Roller (2)
18	981126	Rivet
19	2182338	Clip, Heater
20	489373	Screw
21	531933	Grommet
28	2218994	Compressor (Includes Items 12,13,14,29 & 32)
29		Drier
	2199167	Production
	4387019	Service
30	2155774	Clamp
32		Capacitor
	2169373	Production
	4387764	Service
39	2198921	Air Baffle
40	2188537	Motor, Condenser
42	2187385	Wire Assembly Unit
43	2190685	Fan Blade
44	486692	Nut
45	2212603	Tube, Transition
46	2205384	Tube, Discharge
47	2219622	Tube, Suction
48	2154109	Tube, Process
56	488500	Screw
58	2210451	Tray, Evaporator

Illus. No.	Part No.	DESCRIPTION

Following Parts Not Illustrated and Optional Parts Not Included

	978025	Valve, Access (1/4")
	978026	Valve, Access (5/16")
	978027	Valve, Access (3/8")
	978028	Valve, Access (1/2")
	978029	Valve, Access (5/8")
	978030	Valve, Access (3/4")
	876764	Valve, Access (3/16")

REFRIGERANT CHARGE

4.00 Ozs.
(R134A)

ICEMAKER PARTS

For Models: ET1FTTXKQ02, ET1FTTXKT02, ET1FTTXKB02
(White) (Biscuit) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

ICEMAKER PARTS

For Models: ET1FTTXKQ02, ET1FTTXKT02, ET1FTTXKB02
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION
1	488878	Clamp, Tube
4	2181939	Insert, Tube
5	628379	Clip, Fuse
7	2210514	Tube Water
9	489478	Screw
10	2219594	Valve Solenoid
16	2219592	Valve (Double) Solenoid
18	2210484	Cover
19	489464	Screw
20	628228	Mold & Heater Assembly (Also Order 542638 Silicone Grease)
22	628356	Cup, Water Fill
23	2194711	Ejector
24	2182124	Ice Striper
25	2194712	Support
26	627796	Retainer Thermostat
27	628397	Thermostat (Also Order 542369 Cement Alumilastic)
28	489322	Screw
30	489276	Screw
31	627792	Shut Off Arm
32	2187464	Harness, Wiring
33	628320	Bracket
35	628399	Module Assembly (Includes Item 38)
38	489136	Screw, 3−24 x 23/64
39	488208	Screw
40	488886	Screw, 8−18 x 1/2
41	489442	Screw
100	4317943	Icemaker, Complete Assembly

SHELF PARTS

For Models: ET1FTTXKQ02, ET1FTTXKT02, ET1FTTXKB02
(White) (Biscuit) (Black)



Illus. No.	Part No.	DESCRIPTION
1	2210522	Shelf, Ladder (2)
2	2202821	Shelf, Ladder Center
3	2163762	Cup, Shelf Mtg.
4	3400065	Screw (2)
5	489478	Screw
6	2216624	Egg Bin
9	2210524	Crisper Cover
10	2214909	Shelf, Cantilever
11	2210573	Insert, Crisper Cover
12	2214909K	Pan, Shelf Cantilever
13	2214913	Glass, Shelf
15	2163832	Crisper Support
17	2184667	Shelf, Freezer
20	2218132K	Pan, Meat
21	2214892	Track, Pan Slide (2)
22	2176219	Bucket, Ice
24	2218124	Crisper Pan

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

WATER DISPENSER PARTS

For Models: ET1FTTXKQ02, ET1FTTXKT02, ET1FTTXKB02
(White) (Biscuit) (Black)



Illus. No.	Part No.	DESCRIPTION
1	2210500	Housing, Dispenser
2	2210567	Button, Dispenser
3	2210513	Reservoir, Tube
4	2210523	Flange, Tube
5	2187291	Wire Assembly
6	2162361	Switch
7	2210547	Shield, Switch
8	489415	Screw 8−18 x 1 1/4 (2)

OPTIONAL PARTS

For Models: ET1FTTXKQ02, ET1FTTXKT02, ET1FTTXKB02
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION

Parts Not Illustrated and Optional Parts (Not Included)

	978941	Insulation, Fiberglass (63−1/2" x 35−1/2" x 2−5/8")
	212643	Sealer, Gum (4 Feet)
	479502	Tape, Vinyl (3/4" x 108")
	876305	Kit, Insulation (14 Pcs. 3" x 24" x 48")
	876370	Kit, Insulation (2 Pcs. 3" x 24 " x 48")
	876029	Kit, Foam Slab (30" x 32−1/2" x 1−1/2")
	505587	Sealer, Mastic (1 Qt.)
	511873	Touch−Up, White Porcelain (2 Oz.)
	542638	Grease, Silicone (1/2 Oz.)
	542639	Cement, Alumilastic (1−1/4 Oz.)
	606755	Bag, Insulation (36−5/8" x 46")
	799833	Kit, Evaporator Repair (Aluminum Epoxy)
	799832	Kit, Porcelain Repair (White)
	503695	Cork Sealer (1/4 Pound)

Customer Touch−Up Material

	*350942	Primer, White (12 Oz. Spray Can)
	*350939	Enamel, Black (12 Oz. Spray Can)
	*350930	Enamel, White (12 Oz. Spray Can)
	*350956	Enamel, Almond (12 Oz. Spray Can)
	*4392901	Enamel, Biscuit (12 Oz. Spray Can)
	72017	Brush Touch−Up Kit (White)
	72032	Brush Touch−Up Kit (Black)
	72107	Brush Touch−Up Kit (Almond)
	4392899	Brush Touch−Up Kit (Biscuit)

*__Caution:__ The spray paint is not to be used where the paint may make contact with the door gaskets.

Refinishing Material

	799344	Enamel, White
	799340	Enamel, Black (1 Qt. Uncut)
		(1 Qt. Uncut)
	978883	Enamel, Almond (1 Qt. Uncut)
	4392900	Enamel, Biscuit (1 Qt. Uncut)
	833938	Kit, Terminal Connector

TORX SCREW WRENCH

	1117510	Torx Key